Service Service

Philips Domestic Appliances and Personal Care

Note: This kit is not suitable for Vision (HR8701-8982) or Mobilo (HR8501-8582) types! To service Vision/Mobilo types please refer to the latest service manual of concerned type.

To replace in		Instruction	Illustration
		Instruction	mustration
	HR8352-HR8365 HR8368-HR8378 FC8380-FC8388 FC8390-FC8399 S FC8400-FC8412 FC8600-FC8629 FC9050-FC9079 FC9150-FC9179 FC9200-FC9229	Use snap bracket in the two big holes at motor backside (see fig.1)	Fig.1
Universe Specialist	FC9000-FC9049 FC9100-FC9149	Use snap bracket in the two big holes at motor backside (see fig.1) Remove the Receptacle Housing from the wires or cut off the two clamps! (see fig.2)	Remove housing Or cut off clamps Fig.2
City Line II	FC8421-FC8439	Use the rubber Buffer Back in the two small holes at the motor backside (see fig.3)	Fig.3

In all cases special care should be taken to assure correct mounting in all motor buffers before closing the motor cap!

Published by Philips Domestic Appliances and Personal Care Printed in the Netherlands @ Copyright reserved

Subject to modification

